



Fisher Labs

5-YEAR LIMITED WARRANTY

This product is warranted against defects in materials and workmanship under normal use for five years from the date of purchase to the original owner. Liability in all events is limited to the purchase price paid. Liability under this Warranty is limited to replacement or repair, at our option, of the product returned, shipping cost prepaid, to Fisher Research Labs. Damage due to neglect, accidental damage or misuse of this product is not covered by the warranty.

Proof of purchase is required to make a claim under this warranty.

NOTE TO FOREIGN COUNTRY CUSTOMERS

This warranty may vary in other countries, check with your distributor for details.

Factory warranty follows the channel of distribution.

Warranty does not cover shipping costs.

Fisher Research Labs.

1465-H Henry Brennan

El Paso, TX 79936

Tel. 915.225.0333 Fax 915.225.0336

OWNERS MANUAL



F-Point

*For Treasure Hunting
and unearthing small
objects*

After identifying the presence of a metal object in the ground, pinpointing its exact location, and separating it from the earth, can be frustrating and time consuming.

With the F-Point, retrieving coins and other small metal objects is easy.

Unearthing Small Objects

A buried object, especially after the passage of times, can be indistinguishable from the soil it is buried in. In addition, historical objects will lose value if damaged in the unearthing process.

It is therefore recommended to use the F-Point in a probing or sifting process. The tip of the F-Point will detect a coin-sized metal object approximately 3/4" to 1" away from the tip of the probe. Probe the tip of the F-Point directly into the ground; poke around directly on the surface in different areas until the internal buzzer activates. If the earth is loose enough, lift handfuls of soil out of the ground and probe in the palm of your hand with the F-Point.

Assembly

- No Assembly Required

Operation

- 1. Click On** by rotating the knob clockwise.
- 2. Battery Check**
The F-Point will buzz immediately, indicating that the batteries are in good condition.
If the buzzer does not sound after switching on, replace the single 9-volt battery.
- 3. Rotate the knob** until the buzzer sound stops.
- 4. Set the Sensitivity**
 - With the buzzer silent, **rotate knob back counterclockwise** to the point where the device is just silent.
 - You want to position the knob in the **most counterclockwise position at which the buzzer is still silent**. This threshold setting allows you to always set the device at maximum sensitivity.

